


Window Framing



New Construction Rough Opening Measurements

Measure the distance between studs. You are actually measuring the size of the opening. This is called your Rough Stud Opening (RSO). Measure **WIDTH** from stud to stud. Measure **HEIGHT** from header to sill. There will be a **1" deduction from your width and a 1/2" deduction from your height** so your window will properly fit your RSO opening. This is to allow for the proper plumb installation and shimming of window.



160 Massachusetts Avenue (RT 2A) Lunenburg, MA 01462 Phone: (978) 343-7422 Fax: (978) 345-8351
513 Betty Spring Road Gardner, MA 01440 Phone: (978) 632-5354 Fax: (978) 630-3090

SWS Specialty Wholesale Supply 101 Linus Allain Ave. Gardner MA 01440 a Division of MAKI Corp.
Toll Free: (866) 416-3916 Phone: (978) 630-3916 Fax: (978) 630-4481 Website: SWSCorp.net