


When buying a window, you need to ask the important question:

WHAT IS THE AIR INFILTRATION RATE?



Infiltration Rates

Each block represents 1 Cubic Foot



The SWS Double Hung Window, when independently tested came back **5 times better than the Energy Star Requirement.**



To calculate the Cubic Feet per Minute, first multiply the width by the height of the window and divide by 144. Then, take that number, and multiply that by the tested air infiltration rate. According to Energy Star, the infiltration rate should be less than or equal to .30.